

**QualityGuard+Plus  
Vehicle Protection Plan**

- Nationwide protection at any approved repair facility
- Coverage available for most major makes and models of new and pre-owned vehicles
- Wide variety of time and mileage options
- Choice of \$50 or \$100 deductible
- One deductible per visit
- 100% of labor and parts costs covered (after deductible)
- Direct payment of claim to the repair facility
- Transferable if you sell your vehicle before your contract expires
- Helps to increase resale value of your vehicle
- 24-Hour Roadside Assistance
- Towing
- Car Rental Assistance
- Trip Interruption benefits
- All of our Sr. Claims Adjusters are certified by the National Institute for Automotive Service Excellence

**Disclaimer:**  
THIS BROCHURE, WHICH IS LIMITED BY SIZE, IS NOT A CONTRACT. READ A SAMPLE QUALITYGUARD+PLUS CONTRACT AT YOUR DEALER, AND READ YOUR ACTUAL CONTRACT/SERVICE AGREEMENT WHEN IT ARRIVES IN THE MAIL BECAUSE ITS TERMS, CONDITIONS, EXCLUSIONS, AND LIMITATIONS CONTROL.

**Notice:**  
In compliance with federal laws, the contents of this brochure should be interpreted and understood within the meaning of a "Service Contract" as defined in Federal Law. (See 15 USCS Sec. 2301 (8).)

In Florida, QualityGuard+Plus is backed by Nissan Extended Services North America, Inc., P.O. Box 685004, Franklin, TN 37068-5004. License #60128

Replacement of any part may be made with an approved part of like kind or quality, including a new, remanufactured, aftermarket or used part.

**QualityGuard  
+Plus**  
Vehicle Protection Plan


Enjoy peace of mind with superior mechanical breakdown protection plus roadside assistance benefits.

QUALITY  
GUARD+PLUS

Enjoy worry-free driving with  
**QualityGuard+Plus  
Vehicle Protection Plan**


**Coverage that goes beyond**

Get protection beyond the basic factory warranty with coverage for up to an additional 7 years and 100,000 miles from your purchase date and miles.




**Protection on the road**

Over 50% of all Roadside Assistance calls are due to non-mechanical issues. Roadside Assistance benefits are included with all plans.



**Protected now and in the future**


Shield yourself from the effects of rising inflation on repair costs of major mechanical repairs.



This chart is for illustrative purposes only.

**Protection when you need it**

Help protect yourself against the rising cost of repairs to aging vehicles.



**Personalized Vehicle Protection that covers most makes and models of new and pre-owned vehicles, anywhere the road takes you**

QualityGuard+Plus Vehicle Protection coverage extends to the major components of your vehicle's mechanical performance. You also enjoy the added protection of Roadside Assistance, Towing, Trip Interruption and Car Rental benefits. An overview of the features and components covered under the three available plans is provided below:

**Supreme Plan**

Offers superior coverage of 1,900 components. For the highest level of protection and added peace of mind

**The Most Component Coverage**

The Supreme Plan has coverage so extensive that only a limited number of components are not covered. It even includes In-Dash OEM Audio and In-Dash OEM Navigation coverage.

**Deluxe Plan**

Offers enhanced coverage of over 1,300 components, including:

- Suspension**  
Primary internal and external parts including bushings and bearings
- Steering**  
Primary internal and external parts
- Brakes**  
Primary internal and external parts, including ABS (Anti-Lock Braking System) components
- Electrical**  
Primary electrical components
- Fuel**  
Primary fuel delivery components
- Air Conditioner/Heater (OEM Only)**  
Essential internal and external parts

**Powertrain Plan**

Covers over 700 essential components including:

- Engine**  
Primary internal and external engine components
- Transmission**  
Primary internal and external components for both manual and automatic transmissions
- Drive Axle**  
Primary internal and external components for front-wheel, rear-wheel and four-wheel drive

**Components Covered by Plan**

Supreme	1,900 components
Deluxe	1,300 components
Powertrain	700 components

**QualityGuard+Plus**  
VEHICLE PROTECTION PLAN

**Benefits included with All Plans**

- Roadside Assistance**  
24 hours a day, 365 days a year, including:
  - Emergency Service for battery boost (or jump start), flat tire change (with your good spare), fuel delivery, lock out assistance, plus other minor repairs
  - "Sign and Drive" lets you sign the service order and continue on your way with no out-of-pocket cost to you\*
- Trip Interruption**  
Trip Interruption Coverage reimburses you for meals, lodging and alternative transportation up to \$500 any time your vehicle is disabled due to a mechanical breakdown caused by a covered component and you are more than 100 miles from home. A call to the toll-free assistance center for authorization is required
- Car Rental Assistance**  
Receive reimbursement for car rental expenses up to \$35 per day, to a 5-day maximum, when you need to rent a car while your vehicle is being repaired for a mechanical breakdown caused by a covered component
- Towing**  
Receive up to \$100 in reimbursement when you need to get your vehicle towed due to the failure of a covered component

**Whatever plan you choose, they all provide you:**

- Affordable protection for most makes and models of new and pre-owned vehicles
- A range of cost-effective time and mileage options that guard against the rising costs of repairs
- A choice of \$50 or \$100 deductible on covered repairs
- Nationwide repairs at your retailing dealer or any approved repair facility
- Transferable to a new owner if you sell your vehicle before your coverage expires\*\*
- Convenient and economical coverage can be included in your car payment

\*Up to a maximum of \$100 per claim. Deductibles do not apply to Roadside Assistance services.  
\*\*A nominal transfer fee may apply.  
For complete information concerning components covered, and those components which are excluded from coverage, please refer to the QualityGuard+Plus Service Agreement or contact your local selling dealer.

**Design your own Plan**

Your vehicle's current odometer reading, at time of purchase, will help you design the QualityGuard+Plus Plan that is best for you. Simply answer the questions below and complete the formula to find your ideal plan.

How long do you intend to own your vehicle?  YEARS

How many miles do you drive per year?  MILES

YEARS x  12 =  MONTHS

YEARS x  MILES =  MILES

What is your vehicle's odometer reading?  MILEAGE

Odometer Reading between:	Plans available up to:
0 – 20,000 miles	84 months / 100,000 miles
20,001 – 30,000 miles	72 months / 80,000 miles
30,001 – 40,000 miles	60 months / 70,000 miles
40,001 – 50,000 miles	60 months / 60,000 miles
50,001 – 60,000 miles	48 months / 48,000 miles
60,001 – 75,000 miles	36 months / 36,000 miles
75,001 – 100,000 miles	24 months / 24,000 miles



# The Supreme Plan:

■ Coverage so extensive that only a few items are not covered:

- components of electrically powered vehicles
- paint
- exhaust system
- carpet
- glass
- upholstery
- soft trim
- weather-stripping
- belts and hoses
- moldings
- bright metal
- clutch disc
- air bag sensors
- audio/navigation system components (in-dash OEM† audio/navigation is covered)
- battery and cables
- lenses and bulbs
- tires
- brake drums
- disc brake rotors
- wheels
- shock absorbers
- MacPherson strut inserts
- squeaks
- rattles
- water leaks
- wind noise
- constant velocity boots
- maintenance services
- pressure plate and throw out bearing (manual transmission)
- any and all in-vehicle communications systems

† OEM refers to Original Equipment Manufacturer

For complete information concerning components covered, and those components which are excluded from coverage, read a sample contract at your selling dealer.

## Coverage Overview

Engine	Deluxe	Powertrain
<b>ENGINE AND INTERNAL PARTS</b>		
CAM FOLLOWERS	■	■
CAMSHAFT	■	■
CAMSHAFT BEARINGS	■	■
CONNECTING RODS	■	■
CRANKSHAFT	■	■
CYLINDER BLOCK *	■	■
CYLINDER HEAD *	■	■
ENGINE MOUNTS	■	■
ENGINE OIL COOLER	■	■
FLYWHEEL/FLEX PLATE	■	■
FUEL PUMP	■	■
HARMONIC BALANCER (CRANKSHAFT PULLEY)	■	■
IDLERS	■	■
INTAKE AND EXHAUST VALVES	■	■
LIFTERS	■	■
MAIN BEARING	■	■
MANIFOLDS AND COLLECTOR(S)	■	■
OIL PAN *	■	■
OIL PUMP	■	■
OIL PUMP HOUSING	■	■
OIL SENDING UNIT	■	■
PISTON RINGS	■	■
PISTONS	■	■
PUSH RODS	■	■
RING GEAR	■	■
ROCKER ARM SHAFTS	■	■
ROCKER ARMS	■	■
ROD BEARINGS	■	■
SEALS AND GASKETS	■	■
TENSIONERS	■	■
TIMING COVER *	■	■
TIMING GEARS	■	■
TIMING/BALANCE CHAIN OR BELT	■	■
VALVE COVER *	■	■
VALVE GUIDES	■	■
VALVE SPRING DAMPERS	■	■
VALVE SPRING RETAINERS	■	■
VALVE SPRINGS	■	■
VARIABLE TIMING SOLENOID	■	■
VARIABLE TIMING SOLENOID PRESSURE SWITCH	■	■
* Only covered if damaged by the failure of an internal engine component		
<b>TURBOCHARGER AND SUPERCHARGER **</b>		
ALL INTERNAL COMPONENTS	■	■
INTERCOOLER	■	■
TURBOCHARGER OR SUPERCHARGER VALVES AND ACTUATORS	■	■
Note: Turbocharger or supercharger housings are only covered if damaged by the failure of an internal turbocharger or supercharger part.		
<b>ROTARY ENGINE **</b>		
APEX SEAL	■	■
BEARINGS	■	■
ECCENTRIC SHAFT	■	■
ROTOR	■	■
Note: Rotary engine housing is only covered if damaged by the failure of an internal rotary engine part.		
<b>DIESEL ENGINE **</b>		
GLOW PLUG CONTROLLER/RELAY	■	■
VACUUM PUMP	■	■
<b>LUBRICATION AND COOLING</b>		
FAN AND CLUTCH	■	■
FAN COUPLING	■	■
FAN MOTOR	■	■
OIL PUMP CASE	■	■
RADIATOR	■	■
SEALS AND GASKETS	■	■
SERPENTINE BELT TENSIONER AND IDLER	■	■
WATER PUMP	■	■
<b>Transmission</b>		
<b>TRANSMISSION (Automatic and Manual)</b>		
ALL INTERNAL COMPONENTS	■	■
ELECTRONIC CONTROL UNITS	■	■
OIL COOLER	■	■
SEALS AND GASKETS	■	■
TORQUE CONVERTER	■	■
TRANSMISSION MOUNTS	■	■
Note: Transmission case housing, and oil pan are only covered if damaged by the failure of an internal transmission part.		
<b>Drive Axle</b>		
<b>FRONT WHEEL DRIVE</b>		
ALL INTERNAL COMPONENTS	■	■
CONSTANT VELOCITY JOINTS (SLIDE JOINT SPIDER ASSEMBLIES)	■	■
SEALS AND GASKETS	■	■
Note: Final drive / transaxle case housing and oil pan are only covered if damaged by the failure of an internal front wheel drive part.		
<b>REAR WHEEL DRIVE</b>		
ALL INTERNAL BEARINGS	■	■
ALL INTERNAL COMPONENTS	■	■
AXLE SHAFTS	■	■
CENTER SUPPORT BEARINGS	■	■
COMPANION FLANGES	■	■
LIMITED SLIP ASSEMBLY	■	■
PROPELLER SHAFT(S)	■	■
RING AND PINION	■	■
SEALS AND GASKETS	■	■
SPIDER GEARS	■	■
UNIVERSAL JOINTS (JOURNAL ASSEMBLIES)	■	■
Note: Differential housing is only covered if damaged by the failure on an internal rear wheel drive part.		
<b>ALL WHEEL DRIVE/FOUR WHEEL DRIVE (AWD/4WD)**</b>		
CONSTANT VELOCITY JOINTS (SPIDER ASSEMBLIES)	■	■
FOUR-WHEEL DRIVE ACTUATOR/MOTOR	■	■
INTERNAL TRANSFER CASE COMPONENTS	■	■
LOCKING HUBS	■	■
Note: Transfer case housing is only covered if damaged by the failure of an internal AWD/4WD part.		
** Turbocharger, supercharger, rotary engine, diesel engine, and AWD/4WD are covered only if the applicable option was selected on the QualityGuard+Plus Application at time of purchase and the required additional fee paid.		

Fuel System	Deluxe	Powertrain
<b>FUEL SYSTEM</b>		
CONTROL UNITS	■	■
FUEL INJECTION PRESSURE REGULATOR	■	■
FUEL INJECTION SENSORS	■	■
FUEL INJECTORS	■	■
FUEL PUMP AND FUEL LEVEL SENDING UNIT	■	■
FUEL TANK	■	■
IDLE AIR CONTROL VALVE	■	■
IMRC MOTORS	■	■
KNOCK SENSOR	■	■
METAL FUEL LINES	■	■
MULTI-PORT FUEL INJECTION SYSTEM	■	■
SEALS AND GASKETS	■	■
<b>Suspension</b>		
<b>FRONT AND REAR SUSPENSION</b>		
COIL AND LEAF SPRINGS	■	■
HUBS	■	■
KNUCKLE SPINDLE	■	■
MACPHERSON STRUTS	■	■
REAR ARM ASSEMBLY	■	■
REAR AXLE BEAM	■	■
STABILIZER BARS AND BUSHINGS	■	■
TENSION/COMPRESSION RODS AND BUSHINGS	■	■
TORSION BARS	■	■
UPPER AND LOWER BALL JOINTS	■	■
UPPER AND LOWER CONTROL ARMS (LINKS/TRANSVERSE LINKS) AND BUSHINGS	■	■
WHEEL BEARINGS AND SEALS	■	■
<b>Steering</b>		
<b>STEERING</b>		
POWER CYLINDER ASSEMBLY	■	■
POWER STEERING PUMP AND RESERVOIR	■	■
SEALS AND GASKETS	■	■
STEERING COLUMN MAIN AND UPPER SHAFTS	■	■
STEERING GEAR/RACK AND PINION INTERNAL COMPONENTS	■	■
STEERING LINKAGES AND COUPLINGS	■	■
TILT WHEEL MECHANISM/ACTUATOR	■	■
Note: steering gear and rack and pinion housings are only covered if damaged by the failure of a steering internal part.		
<b>Brakes</b>		
<b>BRAKES</b>		
ANTI-LOCK BRAKING SYSTEM	■	■
BRAKE CALIPERS	■	■
HYDRAULIC VALVES	■	■
HYDRO-BOOSTER	■	■
LINES AND FITTINGS	■	■
MASTER CYLINDER	■	■
SEALS AND GASKETS	■	■
VACUUM ASSIST BOOSTER	■	■
WHEEL CYLINDERS	■	■
<b>Electrical</b>		
<b>ELECTRICAL</b>		
ALTERNATOR	■	■
AUTOMATIC SPEED CONTROL	■	■
CONVERTIBLE TOP MOTOR	■	■
DISTRIBUTOR	■	■
DRIVE COMPUTER DISPLAY	■	■
ELECTRONIC DRIVER INFORMATION DISPLAY AND MODULE (HEAD UP DISPLAY UNIT)	■	■
ELECTRONIC INSTRUMENT CLUSTER	■	■
ENGINE CONTROL MODULE (ECM/PCM)	■	■
FRONT AND REAR WIPER MOTORS AND WASHERS	■	■
H.I.D. BALLAST	■	■
HORN	■	■
IGNITION COIL(S)	■	■
IGNITION MODULE	■	■
IGNITION SWITCH AND MODULE	■	■
MANUALLY AND MECHANICALLY OPERATED SWITCHES	■	■
OEM ANTI-THEFT/KEYLESS ENTRY MODULES	■	■
POWER DOOR LOCK ACTUATORS	■	■
POWER MIRROR MOTORS AND ACTUATORS	■	■
POWER SEAT MOTORS	■	■
POWER WINDOW MOTORS AND REGULATORS	■	■
RELAYS	■	■
STARTER MOTOR AND SOLENOID	■	■
SUNROOF MOTOR	■	■
VOLTAGE REGULATOR	■	■
<b>Air Conditioning</b>		
<b>FRONT &amp; REAR AIR CONDITIONING (OEM ONLY†)</b>		
A/C BLOWER MOTOR RESISTOR (RELAY)	■	■
BLOWER MOTOR	■	■
CLUTCH AND PULLEY	■	■
COMPRESSOR	■	■
CONDENSER	■	■
CONDENSER FAN MOTOR	■	■
EVAPORATOR	■	■
EVAPORATOR THERMISTOR	■	■
HEATER CORE	■	■
RECEIVER DRYER	■	■
SEALS AND VALVES	■	■
TEMPERATURE CONTROL PROGRAMMER	■	■
† OEM refers to Original Equipment Manufacturer		
Seals and gaskets are covered components for leakage failures as they relate to the items listed above. However, seepage is not covered and cannot be claimed under this agreement. Leakage is defined as an actively dripping seal/gasket; seepage is defined as a wet seal/gasket.		

■ = included coverage

For complete information concerning components covered, and those components which are excluded from coverage, please refer to the QualityGuard+Plus Service Agreement or contact your local selling dealer.